

PRODUCT INFORMATION:

SAF- T-STEP® brand N.A.C. Slip Resistant Floor Cleaner and Treatment is a highly effective cleaner formulated for Concrete, Epoxy, Quarry and Ceramic Tiles, Brick, Vinyl and other floor surfaces. Unlike other floor maintenance products, SAF-T-STEP® N.A.C. deep cleans and treats the floor with slip reducing agents which increase the coefficient of friction of the floor surface and reduces the potential for slip and fall accidents. Effective for use on floors in Warehouses, Loading Docks, Industrial Plants, Food Processing Plants, Shopping Malls, Restaurants, Offices, Schools, and anywhere that slips and falls are a problem.

DIRECTIONS FOR USE:**INITIAL SLIP TREATMENT PROCEDURES**

For optimum safety, use this procedure on epoxy, glazed, coated or painted floor surfaces to condition floor or whenever floor surface is out of control with heavy stains or grease build-ups. Apply by mop or automatic scrubber. Reapply initial slip treatment procedure when necessary.

1. DILUTE 8 to 10 ounces N.A.C. per gallon of hot water (12 to 14 ounces N.A.C. per gallon of hot water if using an autoscrubber.)
2. SWISH Mop in N.A.C. solution and leave dripping wet.
3. MOP 10 ft. by 10 ft. area.
4. RINSE mop in bucket to clean mop.
5. WRING mop dry.
6. DAMP mop 10 ft. by 10 ft. area. Allow to dry.
7. REPEAT steps 2 through 6 to finish floor.

Note: For extreme conditions on porous surfaces such as unglazed or unsealed quarry, ceramic, or concrete, SAF- T-STEP® N.A.C. may be used full strength whenever floor surface is out of control. One gallon will effectively "shock clean" 400-500 sq. ft. of floor surface. Follow steps 3, 4 and 5 in the deck brush procedure below. This shock cleaning procedure is only necessary on porous floor surfaces when extreme conditions exist.

DAILY SLIP TREATMENT AND CLEANING PROCEDURES

FOR AUTOMATIC SCRUBBERS: Use 2 ounces per gallon of water. N.A.C. has foam control. For heavy scrubbing, use 4 oz. per gallon of water. ~

DECK BRUSH PROCEDURE: For intensive cleaning of accumulated tough soils in tile and grout.

1. ADD 2-4 oz. N.A.C. to 1 gallon of water.
2. SPREAD N.A.C. solution liberally with mop.
3. SCRUB floor thoroughly with deck brush.
4. RINSE floor thoroughly with clean water.
5. SQUEEGEE soiled solution to drain or central area for easy pick-up. If floor drains are not available, wet vac or damp mop solution off floor in 10 ft. by 10ft. areas.

WET MOP PROCEDURE: For heavy, built-up soils.

1. ADD 2-4 oz. N.A.C. to 1 gallon of hot water.
2. SWISH Mop in N.A.C. solution and leave dripping wet (WET MOP).
3. WET MOP 10 ft. by 10 ft. area.
4. RINSE mop in bucket to clean mop.
5. WRING mop dry (DAMP MOP).
6. DAMP MOP 10 ft. by 10 ft. area. Allow to dry.
7. REPEAT steps 2 through 6 to finish floor.

DAMP MOPPING: (No rinse) procedure for light soils.

This product is self neutralizing and requires no clear water rinse. If rinsing is desired, use SAF- T-STEP® N.A.C. diluted 4 oz. per gallon of water.

1. ADD 2-4 oz. N.A.C. to 1 gallon of water.
2. SWISH Mop in N.A.C. solution.
3. WRING mop dry (DAMP MOP).
4. DAMP mop 10ft. by 10ft. area. Allow to dry.
5. REPEAT steps 2 through 4 to finish floor.